

Use OSREN COATZ 01A Pre-Coating Cleaner to remove any polishing oils and to ensure the best possible bond and durability of OSREN COATZ 02 Absolute Metal Coating. Mist OSREN COATZ 01A Pre-Coating

Spread and buff to clear.

## STEP 2: APPLICATION Wear gloves before application. Soak the included cotton applicator with several drops of OSREN COATZ 02 Absolute Metal Coating. Spread the coating onto the surface. Wait for 1-3 minutes before buffing.

This varies depending on temperature.

The higher the temperature, the sooner

you have to buff.



## CURING PERIOD







## ABSOLUTENESS AWAITS....

The car thanks you for you are about to install the absolute enhancement!

Just follow this application manual step by step and the

coating process will be a breeze.