



Application Manual

What you'll get in this box:

- 1x** 30ml OSREN Coatz 07 Absolute Leather & Vinyl Coating
- 1x** Coating applicator foam
- 3x** Coating applicator
- 1x** Application manual

If any of the above items are missing, please contact your local distributor for more information.

STEP 1 : PREPARATION

- A.** Thoroughly clean surface of all dirt and oils with a water-based cleaner such as OSREN Leather Cleaner, OSREN Fabric Cleaner or OSREN Multi Cleaner.



- B.** Wipe the surface with a damp towel to remove cleaner residue.



- C.** Wipe down the surface with OSREN 01A Pre-Coating Cleaner.



- D.** Ensure the surface is completely dry before application.

STEP 2 : APPLICATION & CURING


- A.** Wear gloves before application.



- B.** Pour a few drops of OSREN COATZ 07 Absolute Leather & Vinyl Coating onto OSREN Microfibre Coating Cloth.




- C.** Spread the product on the surface and ensure it's worked into the grain, crease and texture of the leather and vinyl.



- D.** Gently buff off within 4-8 minutes with an OSREN Buffing Microfibre Towel.



- E.** Optional: Apply a second layer after 2 hours curing at room temperature or after 20 minutes with infrared curing.



- F.** OSREN COATZ 07 Absolute Leather & Vinyl Coating fully cures in 3-4 days, depending on temperature and humidity.

ABSOLUTENESS AWAITS....

The car thanks you for you are about to install the absolute enhancement!

Just follow this application manual step by step and the coating process will be a breeze.